

Installation Instructions



MWL-535

FITMENT:

Dyna Models 06-Up, Street Bob 06-08, & 2010-Up Wide Glides

MAX CAPACITY: 10 lbs

MATERIAL: 3/8" Solid steel & 1/2" tubing outside

TECHNICAL SPECS: May require a fender/seat mounting kit, part # MWL-2000-16

WELCOME: These instructions describe the procedure for properly installing the Motherwell Products Solo Luggage Rack.

ATTENTION INSTALLER (if other than owner):

Please forward this instruction sheet to the purchaser of this product as it contains valuable information necessary to the end user.

CAUTION: Start screw carefully to avoid cross threading.

USE AND CARE:

Wash your accessories with the same care you use when washing your motorcycle. Use mild soap and water. DO NOT use abrasive chemicals, cleaners. We recommend the use of non-abrasive automobile wax to polish our chrome products. This will best maintain the appearance of the product and increase longevity.

WARNING: Never carry more than 10 lbs. on rack, and always secure cargo properly. Failure to do so can affect handling. Make sure neither cargo straps are loose and come in contact with moving parts, i.e., wheels, brakes, etc...

TOOLS REQUIRED:

#2 Phillips Screw Driver

PARTS INCLUDED:

Luggage Rack
2 Phillips 3/4" Pan Head Screws
1 White Nylon Washer
2 Stainless Steel Washers
2 Foam Tabs

MOUNTING PROCEDURE:

- 1) Remove Pillion seat.
- 2) Install foam tabs on back and front of the rack.
- 3) Place rack on fender mounting points. (The forward mount sits on top of the driver's seat)
- 4) Install the stock screw into rear pick up point on the rack. (DO NOT TIGHTEN)
- 5) For the front mount, place the nylon washer on the rack with the stainless steel washer on top.
- 6) From there insert the supplied Phillips screw loosely.
- 7) Proceed to tighten both screws down.

Great Rides Start With Motherwell

Motherwell Products USA, Inc
7040 Portal Way #120
Ferndale, WA 98248
Toll Free (877) 703-7118
www.motherwellproducts.com

Installation Instructions

Great Rides Start With Motherwell

Motherwell Products USA, Inc
7040 Portal Way #120
Ferndale, WA 98248
Toll Free (877) 703-7118
www.motherwellproducts.com